

CKS209 Quick Guide

TIME SETTING

Year → Day → 12/24H → Time

STEP 1



Press **CLOCK SET** for 2 seconds to entry time setting.

Press ▲ or ▼ to adjust the Minute.
Press ◀ or ▶ to adjust the Hour.

STEP 2



Press **CLOCK SET** to next, Month / Date segment will blink.

Press ▲ or ▼ to adjust the Date.
Press ◀ or ▶ to adjust the Month.

STEP 3



Press **CLOCK SET** to next, Year segment will blink.

Press ◀ or ▶ to adjust the Year.

STEP 4



Press **CLOCK SET** to next, 12H / 24H segment will blink.

Press ◀ or ▶ to adjust the time format.

STEP 5

Press **CLOCK SET** again to store the time setting, or wait for 40 seconds.

ALARM SETTING

Time → Volume / Alarm working days

1/2 📢 Wake to Buzzer
1/2 🎵 Wake to Radio

STEP 1



Press and hold the **AL1 / AL2** for 2 seconds, to entry alarm setting.

Press ▲ or ▼ to adjust the Minute.

Press ◀ or ▶ to adjust the Hour.

STEP 2



Press **AL1 / AL2** again, the current volume level and the current day mode will blink.



Press **▲** or **▼** to adjust the Volume.



Press **◀** or **▶** to choose alarm working days.



Single day



Work day



Weekend



Week




STEP 3

Press **AL1 / AL2** again to store the alarm setting, or wait for 40 seconds.

SNOOZE/ STOP/ TURN OFF THE ALARM



1. **SNOOZE** : Alarm will pause 9 minutes for each press, 6 times at most.



2. **Stop the alarm** : Press **AL1 / AL2** when the alarm is ringing.



3. **Turn off the alarm completely** : Press **AL1 / AL2** repeatedly until all the alarm indicator OFF from the display.